

HOW TO USE THE HOSE ADAPTER?

If your swimming pool is equipped with 1¹/₄" outer diameter connection fittings, please read the following instructions:

- 1) Make sure the Hose Clamps are loosely fitted at the ends of the Water Hoses.
- 2) Insert the Hose Adapters to the ends of the Hoses.
- 3) Connect the Hose ends to the Inlet and Outlet ports of the pool.
- 4) Fasten the Hose Clamps.

CÓMO UTILIZAR EL ADAPTADOR DE MANGUERA?

Si su piscina está equipada con 1¹/₄" accesorios de conexión de diámetro exterior, por favor, lea las siguientes instrucciones:

- 1) Asegúrese de que las abrazaderas de manguera están muy ajustada en los extremos de las mangueras de agua.
- 2) Instalar los adaptadores de mangueras a los extremos de las mangueras.
- 3) Conectar la manguera de los extremos a los puertos de entrada y salida de la piscina.
- 4) Fijar las abrazaderas de manguera.

COMMENT UTILISER L'ADAPTATEUR DE TUYAU?

Si votre piscine est équipée d'un raccord de connexion de diamètre extérieur 1-1/4", lisez les instructions suivantes:

- 1) Adaptez les pinces sans les serrer aux extrémités des tuyaux d'eau.
- 2) Insérez les adaptateurs dans les extrémités des tuyaux.
- 3) Connectez les extrémités des tuyaux aux ports d'entrée et de sortie de la piscine.
- 4) Serrez les pinces de tuyau.

